


- | | | | |
|-----------|-----------|-----------|-----------|
| ① ACC | ⑪ ACC-DET | ⑳ NC | ㉑ NC |
| ② SW1 | ⑫ GND | ㉒ NC | ㉒ NC |
| ③ CAN+ | ⑬ CAN- | ㉓ NC | ㉓ NC |
| ④ NC | ⑭ ANT+ | ㉔ AUX-R | ㉔ AUX-L |
| ⑤ AMP-RR+ | ⑮ AMP-RR- | ㉕ NC | ㉕ GND |
| ⑥ AMP-FR+ | ⑯ AMP-FR- | ㉖ NC | ㉖ NC |
| ⑦ AMP-RL+ | ⑰ AMP-RL- | ㉗ LIN-BUS | ㉗ NC |
| ⑧ AMP-FL+ | ⑱ AMP-FL- | ㉘ NC | ㉘ AMP-STB |
| ⑨ ILL+ | ㉙ NC | ㉚ NC | ㉚ NC |
| ⑩ BATT | ㉛ GND | | |



Radio

- ① Front Cam.In ② Ext.MIC In ③ 4CH Audio Out ④ Middle,Bass
 ⑤ AVINI,Ext.TV In ⑥ Ext.Comm.Port(Uart) ⑦ SWC_AD1、2,AUX IN,CAN2,BRAKE
 ⑧ IPOD ⑨ V.Out ⑩ USB ⑪ Rear Cam.In



OPS



TV

RADIO